


141 mm

EÜHOMY
Live the *cool life*




SCAN HERE to activate your warranty
and become part of the Euhomy community!


· Pour the cleaning solution into the water reservoir and let it sit inside the machine for **at least 30 minutes**.



· Then, press the **"Clean"** button to start the cleaning process.
· When the Clean light goes out, remove the drain plug and drain the waste liquid into the sink.



· Repeat with fresh water for two cycles to rinse the inside.
· After draining out all water from the machine, then replace the drain plug.



· Please discard the ice produced during the first 10 minutes of the ice-making cycle before using any ice.



* Check our User Manual for more maintenance ideas.

FAQs

? How often should I clean my ice maker?

To ensure optimal performance, we recommend running the cleaning program daily. It is also recommended that the water in the reservoir be changed every 24 hours to help reduce water hardness and minimize noise. Regular cleaning prevents scale buildup, which can block the pump and cause the machine to malfunction.

? Do I need to fill the water tank and the secondary water reservoir?

Yes, it's recommended that both the main reservoir and the secondary water reservoir be filled to the maximum water level line. The ice machine uses water from the secondary reservoir for ice production, so filling ensures smooth operation and a steady supply of ice.

? Why does machine operate but not make ice?

If the ambient temperature and the refrigeration pipe are in good working order, it is likely that the refrigerant within the machine has experienced a leak. Please provide us with a video or photo of the issue to assist you further. The Euhomy Team will be happy to offer guidance and support.

Please refer to the product manual for more detailed information on:



usage



cleaning



maintenance



troubleshooting

support@euhomy.com

1-833-362-2655(US)

<https://euhomy.com>

EÜHOMY

QUICK GUIDE

for IM017-N Nugget Ice Maker

IM017-NBL-USEH

出血线 3 mm

正面

出血线 3 mm

420 mm

IMPORTANT SAFETY INSTRUCTIONS

 Let the machine sit for **24 hours** on a stable, level surface before first use to allow the refrigerant to settle. **Damage caused by skipping this step is not covered under warranty.**

 Keep the appliance and cord out of children's reach. Close supervision is necessary when used near children.

 Install on a stable surface according to the instructions.

 **DO NOT** store items on top during use.

 **DO NOT** use outdoors or expose to sunlight.

1. SETUP

Unpack

Remove packaging and check accessories (manual, scoop).




Settle Refrigerant

Place the machine on a level surface and let it **sit for 24 hours** to allow the refrigerant to settle before proceeding with setup and use.

Position


Place on a level surface, away from heat, with **6 inches** clearance at the air outlet.



SCAN HERE to watch the installation, usage, cleaning videos and more information.

Plug Accessibility

The power plug must be accessible directly. Position the appliance so that the plug is easily accessible.




2. FIRST-TIME CLEANING BEFORE USE



• **External cleaning:** Turn off the power and clean the exterior of the ice machine with a dry cloth.




• **Clean the ice bin:** Clean with warm water and a soft cloth.




• **Clean the interior:** Clean all internal parts that are recommended to come in contact with water.



*We recommend using our ice maker-specific cleaner.



• **Drain:** Remove the drain plug after cleaning to empty the reservoir. If you use an ice maker-specific cleaner to clean the machine, please use water to clean it again.



• **Install the drain plug again:** After draining is complete, reinstall the drain plug.




• **Run the ice-making cycle:** Run the water for first the 10 minutes of the ice-making cycles, discarding all ice and water to ensure thorough cleaning.

Tip: Please use drinking water, preferably purified bottled water. The quality of the water affects the clarity of the ice and the life of the ice maker.

3. ICE-MAKING PROCESS


Start

Take out the ice bin and fill the water reservoir with potable water - **0.47 gallons maximum**. Replace the ice bin. Plug in the power supply, and the ice maker will enter standby mode.




Making Ice

Press the **ICE** button to start the machine. The machine will begin making ice; if the light is on, it will display white. Press the ICE button again to stop making ice.



Retrieve Ice


Open the lid, scoop the ice, and close the lid for the next cycle.



Indicator On


• **ADD WATER Indicator On:** Please add water to the reservoir and restart the machine if the ADD WATER light is on.

• **ICE FULL Indicator On:** Remove some ice from the ice bin to allow space for new ice. The machine will automatically start a new cycle once there's room.




4. CLEANING & MAINTENANCE

Quick Self-Clean Guide



• In standby mode, press **CLEAN** button, and when the light is turned on during cleaning mode, it will turn blue.



• Drain water and repeat if necessary.

We suggest you clean your ice maker by running the self-cleaning program after each use.

Monthly Clean Guide

Don't forget to deep clean your unit once a month with a special ice machine cleaner and descaler. There are the cleaning steps below: